

# The eSlate VOTING SYSTEM

## A Quick Guide for Voters

6 After finishing your ballot, press the CAST BALLOT button. You will see the American flag on screen indicating your ballot has been recorded.

1 After using the SELECT wheel and ENTER button to enter a 4 number code, the ballot from your precinct appears on screen.



2 Turn the SELECT wheel to move the blue bar over the choice you wish to make.

5 Press the HELP button once to get instructions on the screen; press it twice to ask for help from a pollworker.

4 Use the PREV & NEXT buttons to move back & forth between ballot pages.

3 Press the ENTER button to mark your choice.

# EL eSLATE SISTEMA DE VOTACIÓN

## Una Guía Rápida Para Votantes

6 Después de hacer todas sus selecciones oprima el botón CAST BALLOT. Notará una bandera norteamericana en la pantalla indicando que su voto ha sido registrado.

1 Después de usar la rueda SELECT y el botón ENTER para marcar su clave de 4 números, la papeleta de voto de su precinto aparecerá en la pantalla.



2 Gire la rueda SELECT para mover una barra azul sobre la selección que quiere hacer.

5 Oprima el botón marcado HELP una vez para recibir instrucciones en la pantalla; oprima el botón dos veces para avisar a un trabajador en el sitio de votación que tiene una pregunta.

4 Use los botones PREV y NEXT para moverse entre páginas de la papeleta de voto.

3 Oprima el botón ENTER para marcar su selección.